SHARP

COLOR TELEVISION

MODEL

32R-S400
36R-S400

OPERATION MANUAL



As an ENERGY STAR® Partner, SHARP has determined that this product meets the ENERGY STAR® guidelines for energy efficiency. ENERGY STAR® is a U.S. registered trademark.

CONTENTS

PAGE

- IMPORTANT INFORMATION/IMPORTANT SAFEGUARDS ..... 2 ~ 4
- Supplied Accessories 5
- Before Operating Your Television 5
- Antenna Connections ..... 5 ~ 6
- Quick Reference Control Operation ..... 7 ~ 9
- EZ SETUP during First Use 10
- Demo Mode 11
- Accessing the MAIN MENU screen without Remote Control 11
- Language 12
- Sleep Timer 12
- Video Adjust 13
- Audio Select ..... 14 ~ 15
  - MTS (MULTICHANNEL TV SOUND) 14
  - INTERNAL SPEAKER SWITCH 14
  - FAQ 14

PAGE

- Closed Caption 16
- Parent Control ..... 17 ~ 27
  - V-CHIP ..... 17 ~ 24
  - VIEW TIMER ..... 25 ~ 27
- Energy Save 27
- Set Up ..... 28 ~ 33
  - EZ Setup 28
  - Channel Setting ..... 29 ~ 31
  - Blue Screen 31
  - Personal Preference 32
  - Universal Plus Function 33
- PIP (Picture In Picture) ..... 34 ~ 35
- Using the Video and Audio Input Jacks ..... 36 ~ 37
- Using the Audio Output Jacks 38
- Operation of Remote Control ..... 39 ~ 43
- Before Calling for Service ..... 44 ~ 45
- Calling for Service 44
- Specifications 46
- Limited Warranty 47

This operating manual includes basic operating instructions in Spanish and French.
SPANISH is on page 8, 45.
FRENCH is on page 9.

7366 GJ

Welcome to the SHARP Family. We are pleased that you are now the owner of a SHARP Color Television – built for outstanding quality, reliability and performance.
Every SHARP Color Television set is tuned and adjusted for proper color and sound, and has passed through the most stringent quality control tests at the factory. We have prepared this OPERATION MANUAL so that you may adjust the picture and color to your personal viewing preference.
We sincerely hope that you receive the greatest satisfaction and enjoyment from your new SHARP Color Television set for years to come.
Please read these instructions carefully, and keep them handy for your future reference.

IMPORTANT

To aid reporting in case of loss or theft, please record the TV's model and serial numbers in the space provided. The numbers are located at the rear of the TV.

Model No.:

Serial No.:

IMPORTANT INFORMATION

There are two important reasons for prompt warranty registration of your new SHARP television set, using the REGISTRATION CARD packed in with the set.

FIRST – WARRANTY

This is to assure that you will immediately receive the full consumer benefit of the parts, service and labor warranty applicable to your purchase.

SECOND – CONSUMER PRODUCT SAFETY ACT

To assure that you will promptly receive any safety notification on inspection, modification or recall that SHARP may be required to give under the 1972 Consumer Product Safety Act. PLEASE READ CAREFULLY THE IMPORTANT "LIMITED WARRANTY" CLAUSE ON THE LAST PAGE.

WHAT IS ENERGY STAR ®

TVs and VCRs use energy both when they are on and when they are off. Americans spend more than $1 billion a year on energy consumed by TVs and VCRs when they are not in use. The new ENERGY STAR ® models will reduce that energy "leakage" by up to 75 percent. Ultimately, this will mean more than $500 million a year in energy savings for consumers.

The energy savings will help reduce the burning of fossil fuels and the related carbon dioxide pollution that contributes to global warming. If every American family replaced their TVs and VCRs with ENERGY STAR ® models, it would reduce carbon dioxide emissions by five million tons every year — equivalent to eliminating the pollution from more than one million cars.

By using ENERGY STAR ® products, you will save money on your electric bills and use less energy. That makes good economic sense and it's good for our environment.

WARNING: TO REDUCE THE RISK OF FIRE OR ELECTRIC SHOCK, DO NOT EXPOSE THIS APPLIANCE TO WET LOCATIONS.

CAUTION
RISK OF ELECTRIC SHOCK
DO NOT OPEN
CAUTION: TO REDUCE THE RISK OF ELECTRIC SHOCK,
DO NOT REMOVE COVER (OR BACK).
NO USER-SERVICEABLE PARTS INSIDE.
REFER SERVICING TO QUALIFIED SERVICE PERSONNEL.

The lightning flash with arrowhead within a triangle is intended to tell the user that parts inside the product are a risk of electric shock to persons.

The exclamation point within a triangle is intended to tell the user that important operating and servicing instructions are in the papers with the appliance.

"Note to CATV system installer: This reminder is provided to call the CATV system installer's attention to Article 820-40 of the National Electrical Code that provides guidelines for proper grounding and, in particular, specifies that the cable ground shall be connected to the grounding system of the building, as close to the point of cable entry as practical."

IMPORTANT INFORMATION (Continued)

WARNING – FCC Regulations state that any unauthorized changes or modifications to this equipment not expressly approved by the manufacturer could void the user's authority to operate this equipment.

PRODUCT DISPOSAL

This product utilizes a Cathode Ray Tube (CRT) containing lead and tin lead solder.
Disposal of these materials may be regulated due to environment considerations. For disposal or recycling information, please contact your local authorities or the Electronics Industries Alliance:www.eiae.org

IMPORTANT SAFEGUARDS

CAUTION: Please read all of these instructions before you operate your television and save these instructions for later use.

Electrical energy can perform many useful functions. This unit has been engineered and manufactured to assure your personal safety. BUT IMPROPER USE CAN RESULT IN POTENTIAL ELECTRICAL SHOCK OR FIRE HAZARDS. In order not to defeat the safeguards incorporated in this equipment, observe the following basic rules for its installation, use and servicing.

1. Unplug this television equipment from the wall outlet before cleaning.
2. Do not use liquid cleaners or aerosol cleaners. Use a damp cloth for cleaning.
3. Do not use attachments not recommended by the television equipment manufacturer as they may cause hazards.
4. Do not use this television equipment near water — for example, near a bathtub, washbowl, kitchen sink or laundry tub, in a wet basement, or near a swimming pool, etc.
5. Do not place this equipment on an unstable cart, stand, or table. The television equipment may fall, causing serious injury to a child or an adult, and serious damage to the equipment. Use only with a cart or stand recommended by the manufacturer or sold with the television equipment.
6. Television equipment and cart combination should be moved with care. Quick stops, excessive force, and uneven surfaces may cause the equipment and cart combination to overturn.

7. Wall or shelf mounting should follow the manufacturer's instructions, and should use a mounting kit approved by the manufacturer.
8. Slots and openings in the cabinet and the back or bottom are provided for ventilation. To insure reliable operation of the television equipment and to protect it from overheating, these openings must not be blocked or covered. This television equipment should not be placed in a built-in insulation such as a bookcase unless proper ventilation is provided.
9. The openings should never be covered with a cloth or other material, and the bottom openings should not be blocked by placing the television equipment on a bed, sofa, rug, or other similar surface. This television equipment should never be placed near or over a radiator or heat register.
10. This television equipment should be operated only from the type of power source indicated on the marking label. If you are not sure of the type of power supplied to your home, consult your television dealer or local power company.

    For television equipment designed to operate from battery power, refer to the operating instructions.
11. As a safety feature, television equipment is equipped with a 2-wire polarized plug (one plug blade bigger than the other). The 2-wire polarized plug will fit only one way into the power outlet.

    If the plug does not fit, ask your electrician to replace your obsolete outlet. Do not modify the plug and defeat this safety feature.
12. Do not allow anything to rest on the power cord. Do not locate this television equipment where the cord will be abused by persons walking on it.
13. Follow all warnings and instructions marked on the television equipment.

IMPORTANT SAFEGUARDS (Continued)

14. If an outside antenna is connected to the television equipment, be sure the antenna system is grounded so as to provide some protection against voltage surges and built-up static charges. Section 810 of the National Electrical Code provides information with respect to proper grounding of the mast and supporting structure, grounding of the lead-in wire to an antenna discharge unit, size of grounding conductors, location of antenna-discharge unit, connection to grounding electrodes, and requirements for the grounding electrode.

EXAMPLE OF ANTENNA GROUNDING ACCORDING TO NATIONAL ELECTRICAL CODE.



NEC - NATIONAL ELECTRICAL CODE

15. For added protection for this television equipment during a lightning storm, or when it is left unattended and unused for long periods of time, unplug it from the wall outlet and disconnect the antenna. This will prevent damage to the equipment due to lightning and power-line surges.

16. An outside antenna system should not be located in the vicinity of overhead power lines or other electric light or power circuits, or where it can fall into such power lines or circuits. When installing an outside antenna system, extreme care should be taken to keep from touching such power lines or circuits as contact with them might be fatal.

17. Do not overload wall outlets and extension cords as this can result in fire or electric shock.

18. Never push objects of any kind into this television equipment through cabinet slots as they may touch dangerous voltage points or short out parts that could result in a fire or electric shock. Never spill liquid of any kind on the television equipment.

19. Do not attempt to service this television equipment yourself as opening or removing covers may expose you to dangerous voltage or other hazards. Refer all servicing to qualified service personnel.

20. Unplug this television equipment from the wall outlet and refer servicing to qualified service personnel under the following conditions:
    A. When the power cord or plug is damaged or frayed.
    B. If liquid has been spilled into the television equipment.
    C. If the television equipment has been exposed to rain or water.
    D. If the television equipment does not operate normally by following the operating instructions. Adjust only those controls that are covered by the operating instructions as improper adjustment of other controls may result in damage and will often require extensive work by a qualified technician to restore the television equipment to normal operation.
    E. If the television equipment has been dropped or the cabinet has been damaged.
    F. When the television equipment exhibits a distinct change in performance — this indicates a need for service.

21. Upon completion of any service or repairs to this television equipment, ask the service technician to perform routine safety checks to determine that the television is in safe operating condition.

22. When replacement parts are required, be sure the service technician has used replacement parts specified by the manufacturer that have the same characteristics as the original part. Unauthorized substitutions may result in fire, electric shock, or other hazards.

Supplied Accessories



Infrared Remote Control/Part Number
RRMCG1627CESA

Size AA
Dry Batteries

Before Operating Your Television

Location

- For normal operation, your TV should be located in an area of the room where cool adequate ventilation is provided. Do not place the back of the television set in a place where free airflow will be restricted.
- Any magnetic force may disturb the color picture. Make sure that magnets, electric clocks, toys using magnets or any other magnetic substance, such as iron are kept well away from this TV set.

Power

Your TV operates on 120 Volts, 60 Hertz (normal household current) and has a polarized plug. If you are unable to insert the plug fully into the outlet, try reversing the plug. Should it fail to fit, contact an electrician. Do not defeat the safety feature of the polarized plug.

Note:

- If the set will not be used for a long period, such as during a vacation, unplug the set from the wall outlet to economize power. (If the TV set is plugged in, a slight current still flows, even with the POWER BUTTON in the OFF position.)
- Lines and other noise may appear in TV broadcast images when an FM tuner or radio is located near the TV and both radio and TV broadcasts are being received. Should such noise appear, turn off either the TV or the radio.
- If you are listening to an AM broadcast, turn the TV off. AM broadcast signals may not be received due to the interference of the TV.

■ **Before using the television, prepare the Remote Control**

To use the remote control, insert batteries first.

Insert the batteries



- With your thumbnail, pull up the slit as indicated by the arrow to remove the back cover. Insert two batteries (size “AA”). Be sure to match the battery ⊕/⊖ terminals with the ⊕/⊖ marks inside the compartment.

Antenna Connections

Antennas

- The antenna requirements for good color television reception are more important than those for black & white television reception. For this reason, a good quality outdoor antenna is strongly recommended.

  The following is a brief explanation of the type of connections that are provided with the various antenna systems:

Antenna Connections (Continued)

1. A 75 ohm system is generally a round cable with F-type connector that can easily be attached to a terminal without tools (not supplied).
2. A 300 ohm system is a flat "twin-lead" cable that can be attached to a 75 ohm terminal through a 300-75 ohm ADAPTOR (not supplied).



OUTDOOR ANTENNA CONNECTION

- Use one of the following two diagrams if you connect an outdoor antenna.
  A: Using a VHF/UHF combination outdoor antenna.
  B: Using separate VHF and/or UHF outdoor antenna.
- Connect an outdoor antenna cable lead-in to the COAXIAL CABLE CONNECTOR on the rear of the TV set.

A. Combination VHF/UHF Antennas



B. Separate VHF/UHF Antenna



CABLE TV (CATV) CONNECTION

- A 75 ohm coaxial cable connector is built into the set for easy hookup. When connecting the 75 ohm coaxial cable to the set, screw the 75 ohm cable to the COAXIAL CABLE CONNECTOR.
- Some cable TV companies offer "premium pay channels". Since the signals of these premium pay channels are scrambled, a cable TV converter/descrambler is generally provided to the subscriber by the cable TV company. This converter/descrambler is necessary for normal viewing of the scrambled channels. (Set your TV on channel 3 or 4. Typically one of these channels is used. If this is unknown, consult your cable TV company.) For more specific instructions on installing cable TV, consult your cable TV company. One possible method of utilizing the converter/descrambler provided by your cable TV company is explained below.
  Please note: RF switch equipped with position A/B (not provided) is required.

"A" position on the RF switch (not supplied) : You can view all unscrambled channels using the TV's channel keys.
"B" position on the RF switch (not supplied) : You can view the scrambled channels via the converter/descrambler using the converter's channel keys.



Note:

- Consult your SHARP Dealer or Service Center for the type of splitter, RF switch or combiner that might be required.

Quick Reference Control Operation

■ Location of Controls (ENGLISH)

Front Panel



POWER
Press → On.
Press again → Off.

VOLUME UP/DOWN
(+) Increases sound.
(–) Decreases sound.

VIDEO/AUDIO IN 2 TERMINALS
(VIDEO/AUDIO terminals are also provided on the rear.)

CHANNEL UP/DOWN
(▲) Selects next higher channel.
(▼) Selects next lower channel.
• Press both at the same time to access the MAIN MENU screen.

SENSOR AREA FOR REMOTE CONTROL

Basic Remote Control Functions



Infrared Transmitter Window

POWER
Press → On.
Press again → Off.

REMOTE KEYPAD
Accesses any channel from keypad.

FLASHBACK
Returns to previous channel.

PERSONAL PREFERENCE
With the Personal Preference buttons, you can program your favorite programs by using the 4 categories A, B, C and D. The channels can be accessed quickly by using these buttons. (See page 32.)

VOLUME UP/DOWN
(+) Increases sound.
(–) Decreases sound.
• In menu mode, changes or selects the TV adjustments.

MENU
Press → Accesses MAIN MENU.
Press again → Exits MAIN MENU.

CATV/DVD-TV/VCR MODE SELECT SWITCH
In TV/VCR position, sends power and channel select commands (Channel up/down and Random Access buttons) to the TV and VCR control.
In CATV/DVD position, sends power and channel select commands to a cable TV converter and DVD control.

DVD/VCR CONTROL
See page 39.

DISPLAY
Press → Displays receiving channel for four seconds.
Press again → Removes display.
• Temporarily displays receiving channel when in Closed Caption mode.

INPUT
Press → Switch to external video INPUT 1 mode.
Press 2 times → Switch to external video INPUT 2 mode.
Press 3 times → Switch back to the original TV mode.
See page 37.

ENTER
Used in some instances where a Cable Converter Box requires an "enter" command after selecting channels, when using the REMOTE KEYPAD button. (See page 39)

CHANNEL UP/DOWN
(▲) Selects next higher channel.
(▼) Selects next lower channel.
• See pages 29 ~ 31 for channel presetting.
• Moves the " ⬍ " mark of the MENU screens.

MUTE
Press → Mutes sound.
Press again → Restores sound.
• CLOSED CAPTION appears when sound is muted.

PIP FUNCTION
With the VIDEO inputs, you can watch two pictures at the same time.
See pages 34, 35.

Note:

- The above shaded buttons on the Remote Control glow in the dark. To use the glow-in-the-dark display on the remote control, place it under a fluorescent light or other lighting.
- The phosphorescent material contains no radioactive or toxic material, so it is safe to use.
- The degree of illumination will vary depending on the strength of lighting used.
- The degree of illumination will decrease with time and depending on the temperature.
- The time needed to charge the phosphorescent display will vary depending on the surrounding lighting.
- Sunlight and fluorescent lighting are the most effective when charging the display.

Referencia rápida de los controles de operación

■ Ubicación de los controles (ESPAÑOL)

Panel Delantero



ALIMENTACION (POWER)
Pulsando → Enciende (On).
Pulsando nuevamente → Apaga (Off).

AUMENTO/DISMINUCION DEL VOLUMEN (VOL)
(+) Aumenta el sonido.
(–) Disminuye el sonido.

ZONA DEL SENSOR DEL MANDO A DISTANCIA

TERMINALES DE ENTRADA VIDEO/ AUDIO IN 2
(Los terminales VIDEO/AUDIO también se encuentran en la parte posterior)

CANAL SUPERIOR/INFERIOR (CH) – MENU
(▲) Selecciona el siguiente canal superior.
(▼) Selecciona el siguiente canal inferior.
• Pulse ambos al mismo tiempo para acceder a la pantalla de MENU PRINCIPAL.

Funciones Basicas Del Control Remoto

ALIMENTACION (POWER)
Pulsando → Enciende (On).
Pulsando nuevamente → Apaga (Off).

TECLADO A DISTANCIA (REMOTE KEYPAD)
Para tener acceso a cualquier canal empleando las teclas.

RETORNO AL CANAL ANTERIOR (FLASHBACK)
Para volver al canal anterior.

PREFERENCIAS PERSONALES
Con los botones Personal Preference puede programar sus programas favoritos utilizando las cuatro categorías A, B, C y D.
Puede acceder a los canales rápidamente utilizando estos botones.

AUMENTO/DISMINUCION DEL VOLUMEN (VOLUME UP/DOWN)
(+) Aumenta el sonido.
(–) Disminuye el sonido.
• En modo de MENU cambia o selecciona el ajuste del televisor.

PREPARACION (MENU)
Pulsando → Accede al MENU PRINCIPAL.
Pulsando nuevamente → Sale del MENU PRINCIPAL.

CONMUTADOR SELECTOR DE TELEVISOR/TV POR CABLE (TV-CATV)
En la posición TV, el mando envia los comandos de alimentación y selección de canales (botones de canal superior/inferior y de acceso aleatorio) a un televisor.
En la posición CATV, envia los comandos de alimentación y selección de canales a un convertidor de TV por cable.



Ventanilla del transmisor de infrarrojos

VISUALIZACION (DISPLAY)
Pulsando → Aparece el canal de recepción por cuatro segundos.
Pulsando nuevamente → Elimina la visualización.
• En el modo de "Closed Caption" se muestra el canal de recepción por un corto tiempo.

ENTRADA (INPUT)
Pulsando → Cambia al modo de entrada 1 del vídeo externo.
Pulsando 2 veces → Cambia al modo de entrada 2 del vídeo externo.
Pulsando 3 veces → Vuelve al modo TV original.

INTRODUCIR (ENTER)
Se utiliza en algunos casos en los cuales una Caja de Inversor de Cable requiere una orden "enter" después de seleccionar los canales, al usar el teclado a distancia.

CANAL SUPERIOR/INFERIOR (CHANNEL UP/DOWN)
(▲) Selecciona el siguiente canal superior.
(▼) Selecciona el siguiente canal inferior.
• En el modo de MENU, mueve la marca " ⬍ ".

SILENCIAMIENTO (MUTE)
Pulsando → Silencia el sonido.
Pulsando nuevamente → Restaura el sonido.
• CLOSED CAPTION aparece automáticamente cuando el sonido es silenciado. Siempre y cuando la transmisión tenga esta señal.

CONTROLES DEL DVD/VIDEO

IMAGEN EN IMAGEN (FUNCTION PIP)
Con las entradas VIDEO, se puede ver dos imágenes al mismo tiempo.

Note:

- Los botones que arriba pueden verse sombreados en el Control Remoto lucen en la oscuridad. Para usar el visor del control remoto que luce en la oscuridad, colocarlo bajo una luz fluorescente u otra fuente luminosa.
- El material fosforescente no contiene elementos radiactivos ni tóxicos, de modo que su uso no representa ningún peligro.
- El grado de iluminación variará de acuerdo con la potencia de la luz utilizada.
- El grado de iluminación irá decayendo con el tiempo y dependiendo de la temperatura.
- El tiempo necesario para cargar el visor fosforescente variará de acuerdo con la iluminación circundante.
- La luz del sol y la luz fluorescente son las más eficaces para la carga del visor.

Référence rapide sur les commandes

■ Emplacement des touches (FRANÇAIS)

Panneau Avant



ALIMENTATION (POWER)
Appuyer pour mettre sous tension.
Appuyer de nouveau pour mettre hors tension.

AUGMENTATION/RÉDUCTION DU VOLUME SONORE (VOL)
(+) Pour augmenter le volume du son.
(–) Pour diminuer le volume du son.

ZONE DE DETECTION DU CAPTEUR

PRISES D'ENTRÉE VIDÉO/AUDIO IN 2
(Les prises VIDÉO/AUDIO sont également reprises à l'arrière.)

TOUCHES DES CANAUX CROISSANT/DÉCROISSANT (CH) – MENU
(▲) Sélectionne le canal supérieur suivant.
(▼) Sélectionne le canal inférieur précédent.
• Appuyez simultanément sur ces deux touches pour accéder à l'écran MENU PRINCIPAL.

Fonctions de base de la télécommande



ALIMENTATION (POWER)
Appuyer pour mettre sous tension.
Appuyer de nouveau pour mettre hors tension.

PAVE NUMERIQUE DE COMMANDE A DISTANCE (REMOTE KEYPAD)
Sélectionne directement le canal voulu sur le pavé numérique.

RETOUR (FLASHBACK)
Rappelle le canal regardé précédent.

PREFERENCES PERSONNELLES
Grâce aux touches de préférence personnelle, vous pouvez programmer vos programmes préférés à l'aide des 4 catégories:
A, B, C et D. Ces touches vous permettent d'accéder rapidement à ces canaux.

AUGMENTATION/RÉDUCTION DU VOLUME SONORE (VOLUME UP/DOWN)
(+) Pour augmenter le volume du son.
(–) Pour diminuer le volume du son.
• Pour changer ou sélectionner les réglages du téléviseur en mode menu.

RÉGLAGE (MENU)
Appuyer → Accès au MENU PRINCIPAL.
Appuyer de nouveau → Sortie du MENU PRINCIPAL.

SÉLECTEUR DE MODE DE CÂBLOVISION/DVD-TÉLÉVISION/MAGNÉTOSCOPE (CATV/DVD-TV/VCR)
En position télévision/magnétoscope (TV/VCR), permet de mettre le téléviseur et le magnétoscope sous/hors tension et de sélectionner ses canaux (touche de canaux en ordre croissant/décroissant et d'accès direct).
En position câblovision/DVD (CATV/DVD), permet de mettre un convertisseur de téléviseur par câble et un lecteur de DVD sous/hors tension et de sélectionner ses canaux.

Fenêtre d'émission du signal infrarouge

AFFICHAGE (DISPLAY)
Appuyer pour afficher le canal reçu pendant quatre secondes.
Appuyer de nouveau pour faire disparaître le canal.
• Pour afficher temporairement le canal reçu en mode Sous-titres.

ENTRÉE (INPUT)
Appuyer pour sélectionner le mode ENTRÉE 1 vidéo externe.
Appuyer 2 fois pour sélectionner le mode ENTRÉE 2 vidéo externe.
Appuyer 3 fois pour revenir au mode TV initial.

ENTRER (ENTER)
Parfois utilisée lorsqu'un convertisseur nécessite l'introduction d'une commande "enter" après la sélection de canaux à l'aide du pavé numérique de commande à distance.

TOUCHES DES CANAUX CROISSANT/DÉCROISSANT (CHANNEL UP/DOWN)
(▲) Sélectionne le canal supérieur suivant.
(▼) Sélectionne le canal inférieur précédent.
• Déplace le curseur " ⬍ " sur l'écran du MENU.

SOURDINE (MUTE)
Appuyer → Mise en sourdine du son.
Appuyer de nouveau → Rétablissement du son.
• CLOSED CAPTION apparaît lorsque le son est mis en sourdine.

COMMANDE DU LECTEUR DE DVD/MAGNÉTOSCOPE

IMAGE DANS L'IMAGE (FUNCTION PIP)
Avec les entrées VIDEO, vous pouvez regarder deux images en même temps

Remarque:

- Les boutons ombrés de la télécommande illustrés ci-dessus brillent dans l'obscurité lorsque la télécommande a été placée sous une ampoule fluorescente ou toute autre source lumineuse.
- Le matériau phosphorescent n'est absolument pas toxique ou radioactif. Il peut donc être utilisé en toute sécurité.
- Le degré d'illumination variera en fonction de l'intensité de la source d'éclairage.
- Le degré d'illumination diminuera avec le temps, en fonction de la température.
- Le temps requis pour charger les touches phosphorescentes dépendra de l'éclairage environnant.
- Les rayons directs du soleil et les luminaires fluorescents constituent les meilleures sources de chargement des touches phosphorescentes.

EZ SETUP during First Use

■ **When you turn on the TV for the first time, it will automatically memorize the broadcasting channels.**
Please perform the following instructions before you press the power button.
(1) Insert the batteries into the remote control. (See page 5)
(2) Connect the antenna cable to the TV set. (See page 5 ~ 6)
(3) Plug in the AC POWER cord to the wall outlet.



1 Press the ***POWER*** button on the TV set or on the Remote Control to turn on the TV. The SELECT LANGUAGE mode will be displayed.

(On the Set) **POWER**

(Remote Control) POWER

```
SELECT LANGUAGE

ENGLISH
ESPAÑOL
FRANCAIS
  SELECT:CH▲/▼
  SET   :VOL+/–
```

(SELECT LANGUAGE mode)

2 Press ***CH UP*** **(▲)** or ***DOWN*** **(▼)** to select "ENGLISH", "SPANISH (ESPAÑOL)" or "FRENCH (FRANÇAIS)".

```
SELECT LANGUAGE

ENGLISH
ESPAÑOL
FRANCAIS
  SELECT:CH▲/▼
  SET   :VOL+/–
```

3 Press ***VOL (+)*** or ***(–)*** to access EZ SETUP mode.




```
CONNECT ANTENNA
 OR CABLE.

START EZ SETUP?

          YES:VOL+
          NO :VOL–
```

(EZ SETUP mode)

4 Press ***VOL (+)***.
The tuner will automatically search for the broadcasting and cable TV channels. (The CH No. will automatically increase when it appears.)

If you want to stop the EZ SETUP process once it has started, press ***VOL (–)*** and it will be canceled.

If you want to SETUP again, please refer to page 28 on SETUP.

To cancel EZ SETUP
Press ***VOL (–)***.

```
  PLEASE WAIT

AUTO PROGRAMMING

18
          STOP:VOL–
```

5 Once EZ SETUP is completed, the lowest channel number memorized will be displayed.

```
2
```

Note:

- If EZ SETUP does not memorize all the channels in your region, please refer to page 29 for more information on manually memorizing the channels using CHANNEL SETTING.
- It may be difficult to PRESET when the broadcasting signals are weak, the channel cycle frequency is incorrect or the frequency jamming is occuring around the area. Please refer to pages 29 ~ 31 for more information on manually memorizing the channels using CHANNEL SETTING.

Demo Mode

- To quickly learn more about the TV set, press and hold for more than three seconds both ***CH UP (▲)*** and ***DOWN (▼)*** on the TV set. The TV set will go into DEMO mode and briefly explain the various features.
- To cancel DEMO mode, again press both ***CH UP (▲)*** and ***DOWN (▼)*** on the TV set.

(On the Set)

CHANNEL UP (▲)/ DOWN (▼) buttons

Example:
DEMO mode display

Accessing the MAIN MENU screen without Remote Control

- If you misplaced your Remote Control you can still access most settings via the MAIN MENU screen when you press both ***CH UP (▲)*** and ***DOWN (▼)*** on the TV set.
- Some features of your TV set will not be accessible without the Remote Control. If you lost your Remote Control, contact a Sharp Service Center for a replacement.

(On the Set)

CHANNEL UP (▲)/ DOWN(▼) buttons

Language

- **The language for the ON SCREEN DISPLAY can be set to ENGLISH, SPANISH or FRENCH.**
- **Setting the ON SCREEN DISPLAY Language.**

1 Press ***MENU*** to access MAIN MENU screen.



(MAIN MENU screen)

2 Press ***CH UP*** **(▲)** or ***DOWN*** **(▼)** to move the "⇕" mark to "SET UP".



3 Press ***VOL (+)*** or ***(–)*** to access SET UP mode, then press ***CH UP*** **(▲)** or ***DOWN*** **(▼)** to move the "⇕" mark to "LANGUAGE".





(SET UP mode)

4 Press ***VOL (+)*** or ***(–)*** to access LANGUAGE change mode.



(LANGUAGE change mode)

5 Press ***CH UP*** **(▲)** or ***DOWN*** **(▼)** to select "ENGLISH", "SPANISH (ESPAÑOL)" or "FRENCH (FRANÇAIS)".



6 Press ***MENU*** to exit.

Sleep Timer

- **You can set the number of minutes for your TV to automatically turn off.**

1 Press **MENU** to access MAIN MENU screen.
2 Press **VOL (+)** or **(–)** to access TIMER SET mode.





(MAIN MENU screen)

3 Press **VOL (+)** or **(–)** to set a sleep time of 30, 60, 90 or 120 minutes.
4 Press **MENU** to exit.





(TIMER SET mode)

Note:

- To turn off the Sleep Timer, repeat the above SLEEP TIMER steps and select "– – – REMAIN" during step **3**.
- While SLEEP TIMER is active, the time remaining will be briefly displayed on-screen at regular intervals or when the remote's Display key is pressed.

Video Adjust

Description of Adjustment Items

Selected item	VOL UP (+) button	VOL DOWN (–) button
PICTURE	To increase contrast	To decrease contrast
TINT	To make skin tones greenish	To make skin tones purplish
COLOR	To increase color intensity	To decrease color intensity
BRIGHT	To increase brightness	To decrease brightness
SHARP	To increase sharpness	To decrease sharpness
COLOR TEMP.	To choose a LOW, ML, MH or HIGH COLOR TONE.	
RESET	To return all adjustments to factory preset levels.	



1 Press ***MENU*** to access MAIN MENU screen.

2 Press ***CH UP*** **(▲)** or ***DOWN*** **(▼)** to move the "⬍" mark to "VIDEO ADJUST".





(MAIN MENU screen)

3 Press ***VOL (+)*** or ***(–)*** to access PICTURE adjust mode.





(PICTURE adjust mode)

4 Press ***CH UP*** **(▲)** or ***DOWN*** **(▼)** to select the desired mode. (Refer to the diagram below.)



←: CH UP (▲) →: CH DOWN (▼)

5 Press ***VOL (+)*** or ***(–)*** to adjust the setting.





6 Repeat steps **4** to **5** to adjust other settings.

7 Press ***MENU*** to exit.

Audio Select

- **MTS (MULTI CHANNEL TV SOUND)**
  This circuit allows reception of stereo or bilingual TV sound.
- **INTERNAL SPEAKER SWITCH**
  This function turns the TV's internal speakers "ON" or "OFF" when listening to sound from external speakers by using the AUDIO OUTPUT JACKS on page 38.
- **FAO**
  This function turns the TV's internal speakers "OFF" and allows fixed audio output from the AUDIO OUTPUT JACKS on page 38. With FAO on the TV's volume control is disabled.

1 Press ***MENU*** to access MAIN MENU screen.

2 Press ***CH UP*** **(▲)** or ***DOWN*** **(▼)** to move the "⇕" mark to "AUDIO SELECT".





(MAIN MENU screen)

3 Press ***VOL (+)*** or ***(–)*** to access AUDIO SELECT mode.

4 Press ***CH UP*** **(▲)** or ***DOWN*** **(▼)** to move the "⇕" mark to "MTS", "SPEAKER" or "FAO".





(AUDIO SELECT mode)

5 Press ***VOL (+)*** or ***(–)*** to select "STEREO", "SAP" or "MONO" when the "⇕" mark is at "MTS" position.







(AUDIO SELECT mode)

6 Press ***MENU*** to exit.

Ex: Actual screen indicating ON AIR when receiving STEREO broadcasts

Actual channel number

"← ON AIR" will appear next to STEREO or SAP when receiving STEREO or SAP broadcasts.



(CHANNEL call on screen)

Audio Select (Continued)

■ **You can enjoy Hi-Fi stereo sound or SAP broadcasts where available.**

- Stereo broadcasts
  Live television transmission of sports, shows, concerts, etc. can be received in dynamic stereo sound.
- SAP broadcasts
  Television broadcast can be received with either MAIN or SAP sound.
  MAIN sound: The normal program soundtrack. (Monaural or stereo where available.)
  SAP sound: Second language, supplementary commentaries, etc. (SAP sound is monaural.)

■ **If stereo sound is difficult to hear.**

- You can obtain clearer sound by manually switching to fixed monaural mode.

Note:

- Once MONO mode is selected, the TV sound remains monaural even if the TV set receives a stereo broadcast. You must switch the mode back to STEREO if you want to hear stereo sound again.
- Selecting MTS while in the INPUT mode does not change the type of sound; in this case, sound is determined by the video source.
- If “FAO” mode is select “ON”, “SPEAKER” will automatically turn “OFF”.
  “SPEAKER” selecting will not affect “FAO” mode.

Closed Caption

■ HOW TO SET CLOSED CAPTION

- Your TV is equipped with an internal Closed Caption decoder. “Closed Caption” is a system which allows you to view conversations, narration, and sound effects in TV programs and home videos as subscript on your TV screen as shown on the right.
- Not all the programs and videos will offer closed caption. Please look for the “ CC ” symbol to ensure that captions will be shown.
- Closed Caption broadcast can be viewed in two modes: CAPTION and TEXT. For each mode, two channels are available, CH1 and CH2:

  The [CAPTION] mode subscripts dialogues and commentaries of TV dramas and news programs while allowing clear view of the picture. The [TEXT] mode displays over the picture other various information (such as TV program schedule, weather forecast, etc.) that is independent of the TV programs.



---

1 Press **MENU** to access MAIN MENU screen.

2 Press ***CH UP*** **(▲)** or ***DOWN*** **(▼)** to move the “⇕” mark to “CLOSED CAPTION”.





(MAIN MENU screen)

---

3 Press ***VOL (+)*** or ***(–)*** to access CLOSED CAPTION setting mode.





(CLOSED CAPTION setting mode)

---

4 Press ***CH UP*** **(▲)** or ***DOWN*** **(▼)** to move the “⇕” mark to either “MODE” or “DATA”.



---

5 Press ***VOL (+)*** or ***(–)*** to change the CLOSED CAPTION setting.

MODE : CAPTION ↑↓ TEXT ↑↓ OFF

DATA : CH 1 ↑↓ CH 2





---

6 Press ***MENU*** to exit.

Note:

- If a broadcast has CLOSED CAPTION and the **MUTE** button is pressed, the set enters [CAPTION] mode automatically. Pressing **MUTE** again will return the set to its previous condition.
- Closed Caption may malfunction (white blocks, strange characters, etc.) if signal conditions are poor or if there are problems at the broadcast source. This does not necessarily indicate a problem with your set.
- If any button is pressed to call up the ON SCREEN DISPLAY while viewing a CLOSED CAPTION broadcast, the closed captions will disappear momentarily.
- When viewing in TEXT mode, if no TEXT broadcast is being received, for some programs the screen may become dark and blank. Should this occur, set the Closed Caption mode to “OFF”.

Parent Control (V-CHIP Operation)

■ **V-CHIP**

- This function allows you to restrict TV programs and also allows you to control TV usage based on FCC data. This function is to prevent your children from watching violence or sexual scenes that may be harmful.
- Restriction of TV programs includes two characters that contain information about the program's MPAA rating and the TV Parental Guidelines. MPAA is restricted by age. TV Parental Guidelines are restricted by age and contents.
- Since a TV program may use either the MPAA rating or the TV Guidelines you should adjust both for complete control.

[1] MPAA RATING

RATING		
age base	G	GENERAL AUDIENCES. All ages admitted.
	PG	PARENTAL GUIDANCE SUGGESTED. Some material may not be suitable for children.
	PG-13	PARENTAL STRONGLY CAUTIONED. Some material may be inappropriate for children under 13.
	R	RESTRICTED. Under 17 requires accompanying parent or adult guardian.
	NC-17	NO ONE 17 AND UNDER ADMITTED.
	X	X Rating is an older rating that is unified with NC-17 but may be encoded on older movie's data.

- **MPAA RATING (Example)**

Example 1.

"PG-13" in the age based RATING is blocked, this will automatically block the high ratings "R", "NC-17", "X" also.



Example 2.

"R" in the age based RATING is blocked, this will automatically block the high rating "NC-17", "X" also.



Note:

- MPAA RATING is only age based ratings.

[2] TV PARENTAL GUIDELINES

RATING		⇦ content base ⇨					
		AGE	D (Sexually Suggestive Dialog)	L (Adult Language)	S (Sexual Situation)	V (Violence)	FV (Fantasy Violence)
⇧ age base ⇩	TV-Y (All children)	V	–	–	–	–	–
	TV-Y7 (Direct to Older Children)	V	–	–	–	–	V
	TV-G (General Audience)	V	–	–	–	–	–
	TV-PG (Parental Guidance Suggested)	V	V	V	V	V	–
	TV-14 (Parents Strongly Cautioned)	V	V	V	V	V	–
	TV-MA (Mature Audience Only)	V	–	V	V	V	–

V : Content Rating can be set.

– : Content Rating can not be set (not normally broadcast by TV station).

Parent Control (V-CHIP Operation Continued)

- **TV-PARENTAL GUIDELINES (Example)**

Example 1.1 : Age Based setting
Go through all select ratings and select unblocked for “AGE”.
This will automatically unblock everything.



Example 1.2 : Age Based setting
For “TV-G” select “BLOCK” for “AGE”. This will automatically block the higher age ratings “TV-PG”, “TV-14” and “TV-MA” as well as “TV-G”. Furthermore, the content ratings “D”, “L”, “S”, “V”, “FV” are automatically blocked as well for “TV-PG”, “TV-14” and “TV-MA” as well as “TV-G”.



Example 2.1 : Content Based setting
For “TV-PG”, “TV-14” and “TV-MA” select unblocked for each content ratings (“D”, “L”, “S”, “V”, “FV”) by leaving “AGE” unblocked for “TV-PG”, “TV-14” and “TV-MA”. If you choose to unblock for each one in content base.



Example 2.2 : Content Based setting
Then for “TV-PG” and select “BLOCK” for only “V” (Violence). This will automatically block the higher ratings “TV-14-V” and “TV-MA-V” (“TV-14” and “TV-MA” for Violence content only).
Please note that with these settings blocking does NOT occur. If a program is rated only “TV-MA”; it must be rated “TV-MA-V” to be blocked.



Example 3 : Reset an Age Based setting
For “TV-14” and select again “BLOCK” for “AGE”.
This will again automatically block the content ratings “D”, “L”, “S”, “V”, “FV” for “TV-MA” as well as “TV-14”.
Please note that the lower age rating “TV-PG” did not change from its previous settings.



Note:

- Content ratings can be modified but only in the combinations indicated by an V in the table on page 17.
- Changing a lower age rating’s content setting to “BLOCK” automatically changes the same higher age rating’s content setting to “BLOCK” regardless of their previous settings.
- Changing a lower rating’s “AGE” setting to “BLOCK” automatically changes all higher ratings to “BLOCK” regardless of their previous settings.
- Any rating’s “AGE” set to unblocked must have its content settings individually set.

[3] ADDITIONAL MODE
Besides the above “MPAA RATINGS” and “TV PARENTAL GUIDELINES” new ratings system’s data can be downloaded when they become available. (See page 21.)

Parent Control (V-CHIP Operation Continued)

■ HOW TO SET V-CHIP



[1] MPAA RATING

1 Press ***MENU*** to access MAIN MENU screen.

MENU



(MAIN MENU screen)

2 Press ***CH UP (▲)*** or ***DOWN (▼)*** to move the "◆" mark to "PARENT CONTROL".

CH▲

CH▼



3 Press ***VOL (+)*** or ***(–)*** to access PARENT CONTROL mode, then "PARENT CONTROL V-CHIP BLOCK" is displayed.

VOL — VOL +



(PARENT CONTROL mode)

4 Press ***VOL (+)*** or ***(–)*** to access V-CHIP select mode, then press ***VOL (+)*** or ***(–)*** to select "MPAA RATING".

VOL — VOL + → VOL — VOL +



(V-CHIP select mode)

5 Press ***CH UP (▲)*** or ***DOWN (▼)*** to move the "◆" mark to "PG", then press ***VOL (+)*** or ***(–)*** to select BLOCK. If you set "PG" to BLOCK, "PG-13", "R", "NC-17" and "X" are automatically blocked.

CH▲ CH▼ → VOL — VOL +



6 Repeat pressing ***MENU*** to return V-CHIP select mode exit.

MENU

Note:

Ex.

- If you set "G" to BLOCK , all RATING are automatically blocked.
- If you set "X" to BLOCK, "G", "PG", "PG-13", "R" and "NC-17" are not blocked.

Parent Control (V-CHIP Operation Continued)

[2] TV GUIDELINES

1 Repeat steps **1** to **3** of **[1] MPAA RATING**.

2 Press ***CH UP (▲)*** or ***DOWN (▼)*** to move the "⬍" mark to "TV GUIDELINES".



3 Press ***VOL (+)*** or ***(–)*** to access TV GUIDELINES mode.





(TV GUIDELINES mode)

4 To change CONTENT SETTING, press ***CH UP (▲)*** or ***DOWN (▼)*** to move the "⬍" to the desired rating and then press ***VOL (+)*** or ***(–)*** to select.



5 Press ***CH UP (▲)*** or ***DOWN (▼)*** to move the "⬍" to the desired content and then press ***VOL (+)*** or ***(–)*** to select either "BLOCK" or unblock ("– – – –").





(CONTENT RATING mode)

6 Press ***MENU*** to return to TV GUIDELINES mode.



7 Repeat steps **4** to **5** until all ratings and their contents are set.

8 When done, press ***MENU*** to exit.

Parent Control (V-CHIP Operation Continued)

[3] ADDITIONAL MODE (DOWNLOAD)
There will be an additional new rating system. In that case, please set up as follows. Subsequently the new rating system will set up automatically.

1 Repeat steps **1** to **3** of **[1] MPAA RATING**.

2 Press ***CH UP (▲)*** or ***DOWN (▼)*** to move the "⬍" mark to "DOWNLOAD".



3 Press ***VOL (+)*** or ***(–)*** to "DOWNLOAD : ON".





4 Repeat pressing ***MENU*** to return exit.

- **DOWNLOAD V-CHIP DATA**



1 If you watch the program with "New Rating System Data", DOWNLOAD screen will be displayed.



(DOWNLOAD screen)

2 DOWNLOAD screen will disappear, if DOWNLOAD is finished.

Note:

- DOWNLOAD would not be started, if you don't watch the program with "New Rating System Data".

Parent Control (V-CHIP Operation Continued)

• ADDITIONAL MODE (Example)

1 Repeat steps **1** to **2** of **[3] ADDITIONAL MODE**.

2 Press ***CH UP (▲)*** or ***DOWN (▼)*** to move the "◆" mark to "Cdn. English Ratings", then press ***VOL (+)*** or ***(–)***.




```
 MPAA
 TV GUIDELINES
◆Cdn. English Ratings
 Cdn. French Ratings


 DOWNLOAD:ON
 STATUS  :ON
```

(After download the rating data)

3 You can select "BLOCK" or "– – – – –" (unblock) from each RATING mode by pressing ***CH UP (▲)*** or ***DOWN (▼)*** and ***VOL (+)*** or ***(–)***.




```
◆C          :-----
 C8+        :BLOCK
 G          :-----
 PG         :BLOCK
 14+        :-----
 18+        :BLOCK

 INDIVIDUAL BLOCK

      MENU:RETURN
```

(ENGLISH INDIVIDUAL BLOCK mode)

4 You can select "BLOCK" or "– – – – –" (unblock) from each RATING mode by pressing ***CH UP (▲)*** or ***DOWN (▼)*** and ***VOL (+)*** or ***(–)*** if you select "Cdn. French Ratings" in step **2**.




```
◆G          :-----
 8+         :BLOCK
 13+        :-----
 16+        :BLOCK
 18+        :-----


 INDIVIDUAL BLOCK

      MENU:RETURN
```

(FRENCH INDIVIDUAL BLOCK mode)

Note:

- **In additional mode**
  Including two types (English mode, French mode), altogether you are able to download 4 kinds of mode.

Parent Control (V-CHIP Operation Continued)

■ ACTIVATE ON TO TURN ON V-CHIP BLOCK

1 Repeat steps **1** to **3** of **[1] MPAA RATING**.

2 Press ***CH UP (▲)*** or ***DOWN (▼)*** to move the "⇕" mark to "STATUS", then press ***VOL (+)*** or ***(–)*** to activate ON the V-CHIP BLOCK. (If STATUS is OFF, V-CHIP BLOCK will not be operated.)




```
MPAA
TV GUIDELINES

DOWNLOAD:OFF
⇕STATUS  :ON
```

3 Press ***MENU***, then "INPUT SECRET No." will be displayed.

```
INPUT SECRET No.

- - - -
```

4 Enter the 4-digit SECRET No. using the ***REMOTE KEYPAD***.

```
INPUT SECRET No.

1 2 3 4
```

5 Press ***MENU*** and SECRET No. is registered.

■ To cancel the V-CHIP BLOCK screen while V-CHIP BLOCK has been activated.

1 "V-CHIP HAS BEEN ACTIVATED" will be displayed if you watch the program with Program Rating data as same as you configured.

```
                23
V-CHIP HAS BEEN
  ACTIVATED

      TV-Y7
      FV
```

Note:

- "V-CHIP HAS BEEN ACTIVATED" will not be displayed if STATUS is not configured to "ON".

2 Press ***MENU***, then "INPUT SECRET No." will be displayed.

```
INPUT SECRET No.

- - - -
```

3 Enter the 4-digit SECRET No. using the ***REMOTE KEYPAD***, then V-CHIP BLOCK temporarily will be canceled. If the wrong SECRET No. is chosen, "SECRET No. IS INCORRECT" will be displayed. Input the SECRET No. again in this case.

```
INPUT SECRET No.

* * * *
```

Note:

- If you change Power from OFF to ON, then V-CHIP BLOCK will be activated ON again.

Parent Control (V-CHIP Operation Continued)

■ **To change the V-CHIP BLOCK setting. (Secret No. is registered.)**

1 Repeat steps **1** to **3** of **[1] MPAA RATING**, then "INPUT SECRET No." will be displayed.



2 Enter the 4-digit SECRET No. using the ***REMOTE KEYPAD*** and the V-CHIP select mode will be displayed. Repeat configuration of the V-CHIP BLOCK.



■ **If you intend to change or forget your Secret No., clear the original Secret No. and set up a new one.**

1 Repeat steps **1** to **3** of **[1] MPAA RATING**, or **1** to **2** of **[■ To cancel the V-CHIP BLOCK screen while V-CHIP BLOCK has been activated]**, then "INPUT SECRET No." will be displayed.

2 Press and hold both ***VOL (+)*** and ***CH DOWN (▼)*** on the TV set simultaneously until the message "INPUT SECRET No." disappears.

(On the Set)



VOL (+)/CHANNEL DOWN (▼) buttons

3 Press ***MENU*** two times to exit.

Parent Control (VIEW TIMER)

■ **VIEW TIMER**

This function allows you to restrict TV viewing time and also allows you to control TV usage. This function is to prevent your children from watching too much TV.

VIEWING TIME (an accumulative timer: counts only the time duration acquired while the TV is on.)

- VIEWING TIME can be set from 30M (30 minutes) to 10H00M (10 hours) in 30 minutes intervals.

OFF TIME (Restricts TV watching after the VIEWING TIME reaches zero.)

- OFF TIME can be set from 30M (30 minutes) to 10H00M (10 hours) in 30 minutes intervals.

STATUS (ON/OFF setting of VIEW TIMER)



■ **How to set VIEW TIMER.**

1 Press ***MENU*** to access MAIN MENU screen.

2 Press ***CH UP*** **(▲)** or ***DOWN*** **(▼)** to move the "⇕" mark to "PARENT CONTROL".





(MAIN MENU screen)

3 Press ***VOL (+)*** or ***(–)*** to access PARENT CONTROL mode.

4 Press ***CH UP*** **(▲)** or ***DOWN*** **(▼)** to move the "⇕" mark to "VIEW TIMER".





(PARENT CONTROL mode)

5 Press ***VOL (+)*** or ***(–)*** to access "VIEW TIMER".





6 Press ***CH UP*** **(▲)** or ***DOWN*** **(▼)** to select "VIEWING TIME" and "OFF TIME". For each selection, press the ***VOL (+)*** or ***(–)*** to set the time duration.





7 Press ***CH UP*** **(▲)** or ***DOWN*** **(▼)** to select "STATUS". Press the ***VOL (+)*** or ***(–)*** to turn ON the "VIEWING TIMER". (If STATUS is OFF, VIEW TIMER is not operated)





8 Press ***MENU***. "INPUT SECRET No." will be displayed.



Parent Control (VIEW TIMER Continued)

9 Enter the 4-digit SECRET No. using the ***REMOTE KEYPAD***.

10 Press ***MENU***, and SECRET No. is registered.





Example

- To restrict anybody from watching the TV for 5 hours, after watching the TV for 2 hours, your settings would look like this:
- They can choose to watch the 2 hours of TV however they wish. For example, they could watch 1 hour of TV, turn TV off for 30 minutes, then turn TV on and watch the remaining 1 hour on the VIEWING TIMER.



■ **To change the VIEW TIMER settings. (SECRET No. is registered)**

1 Repeat "How to set VIEW TIMER" steps and select "PARENT CONTROL VIEW TIMER" during step **3**. Press ***VOL (+)*** or ***(–)***, and "INPUT SECRET No." will be displayed.





2 Enter the 4-digit SECRET No. using the ***REMOTE KEYPAD***, and the VIEW TIMER access screen will be displayed. Repeat step **5** ~ **6**.



Note:

- When you choose the correct SECRET No., the VIEW TIMER access screen is displayed. If the wrong SECRET No. is chosen, "SECRET No. IS INCORRECT" is displayed. Input the SECRET No. again in this case.



■ **To cancel the VIEW TIMER (While the TV set is OFF but the VIEW TIMER is set)**

1 Turn on TV; a blue screen message "TIME OVER" will appear. If you do nothing, the TV will turn off in approximately 30 seconds.



2 Enter the 4-digit SECRET No. using the ***REMOTE KEYPAD***. When you choose the correct SECRET No., the VIEW TIMER is canceled. If the wrong SECRET No. is chosen, "SECRET No. IS INCORRECT" is displayed. Input the SECRET No. again in this case.



■ **To cancel the VIEW TIMER setting or change the SECRET No. (When you forget the SECRET No.)**

1 Repeat "How to set VIEW TIMER" steps and select "PARENT CONTROL VIEW TIMER" during step **3**. Press ***VOL (+)*** or ***(–)***, and "INPUT SECRET No." will be displayed.





Parent Control (VIEW TIMER Continued)

2 Press and hold both ***VOL (+)*** and ***CH DOWN (▼)*** on the TV set simultaneously until the VIEW TIMER access screen is displayed. Now you can cancel the VIEW TIMER settings or can change the SECRET No. while "INPUT SECRET No." is displayed.

(On the Set)



VOL (+)/CHANNEL DOWN (▼) buttons

■ **Notice of Remaining VIEWING TIME**

- For every 30 minute interval, the "remaining time" will be displayed for 4 seconds. For the last 5 minutes, the "remaining time" will be displayed every minute.
- "0 REMAIN" will be displayed for 10 seconds just before the VIEWING TIME is completed.



Energy Save

■ **This feature lets you lower the power consumption of your TV set which in turn saves you money and minimizes the impact on the environment. When this feature is turned on, it reduces the brightness of the TV to a level that consumes approximately 20 percent less energy than when the feature is turned off.**
The reduction in brightness will be less noticeable under low room lighting conditions.



1 Press **MENU** to access MAIN MENU screen.

2 Press ***CH UP (▲)*** or ***DOWN (▼)*** to move the "⬍" mark to "ENERGY SAVE".





(MAIN MENU screen)

3 Press ***VOL (+)*** or ***(–)*** to access ENERGY SAVE select mode.





(ENERGY SAVE select mode)

4 Press ***VOL (+)*** or ***(–)*** to select "ON".





5 Press ***MENU*** to exit.

Set Up

■ **EZ SETUP**

By operating the channel presetting functions, you can preset your TV to the desired channels for viewing.



1 Press ***MENU*** to access MAIN MENU screen.

2 Press ***CH UP*** **(▲)** or ***DOWN*** **(▼)** to move the "◆" mark to "SET UP".




```
TIMER
VIDEO ADJUST
AUDIO SELECT
CLOSED CAPTION
PARENT CONTROL
ENERGY SAVE
◆SET UP
```

(MAIN MENU screen)

3 Press ***VOL (+)*** or ***(–)*** to access SET UP mode, then press ***CH UP*** **(▲)** or ***DOWN*** **(▼)** to move the "◆" mark to "CH SETTING".




```
BLUE SCREEN
PERSONAL PREF.
UNIVERSAL PLUS
LANGUAGE
◆CH SETTING
```

(SET UP mode)

4 Press ***VOL (+)*** or ***(–)*** to access CH SETTING mode.




```
◆EZ SETUP
AIR/CABLE
CH SEARCH
CH MEMORY
```

(CH SETTING mode)

5 Press ***VOL (+)*** or ***(–)*** to access EZ SETUP mode.




```
CONNECT ANTENNA
 OR CABLE.

START EZ SETUP?

          YES:VOL+
          NO :VOL–
```

(EZ SETUP mode)

6 Press ***VOL (+)***.
The tuner will automatically search for the broadcasting and cable TV channels. (The CH No. will automatically increase when it appears.)

If you want to stop the EZ SETUP process once it has started, press ***VOL (–)***. Search will be canceled.

```
  PLEASE WAIT

AUTO PROGRAMMING

18
          STOP:VOL–
```

To cancel EZ SETUP
Press ***VOL (–)***.

7 Once EZ SETUP is completed, the lowest channel number memorized will be displayed.

```
2
```

Set Up (Continued)

■ **CHANNEL SETTING**

If EZ SETUP does not memorize all the channels in your region, follow the instructions below to manually memorize the channel.

1 Press ***MENU*** to access MAIN MENU screen.

2 Press ***CH UP*** **(▲)** or ***DOWN*** **(▼)** to move the "⇕" mark to "SET UP".





(MAIN MENU screen)

3 Press ***VOL (+)*** or ***(–)*** to access SET UP mode.

4 Press ***CH UP*** **(▲)** or ***DOWN*** **(▼)** to move the "⇕" mark to "CH SETTING".





(SET UP mode)

5 Press ***VOL (+)*** or ***(–)*** to access CH SETTING mode.





(CH SETTING mode)

6 Press ***CH UP*** **(▲)** or ***DOWN*** **(▼)** to move the "⇕" mark to "AIR/CABLE", then press ***VOL (+)*** or ***(–)*** to access AIR/CABLE mode.





7 Press ***CH UP*** **(▲)** or ***DOWN*** **(▼)** to move the "⇕" mark to the desired mode.





(AIR/CABLE mode)

8 Press ***MENU*** to exit.

Note:

- Receivable channels of your TV set are:

AIR channels:
VHF: 2 through 13.
UHF: 14 through 69.

CABLE channels:
1 (HRC and IRC mode only)
2 through 125 (STD, HRC and IRC)

Set Up (Continued)

■ **Saving broadcast TV channels into memory.**

1.1 Press ***MENU*** to access MAIN MENU screen, then press ***CH UP*** (▲) or ***DOWN*** (▼) to move the "⇕" mark to "SET UP".

1.2 Press ***VOL (+)*** or ***(–)*** to access SET UP mode, then press ***CH UP*** (▲) or ***DOWN*** (▼) to move the "⇕" mark to "CH SETTING".

1.3 Press ***VOL (+)*** or ***(–)*** to access CH SETTING screen.

1.4 Press ***CH UP*** (▲) or ***DOWN*** (▼) to move the "⇕" mark to "CH SEARCH", then press ***VOL (+)*** or ***(–)*** to access CH SEARCH screen.




```
EZ SETUP
AIR/CABLE
●CH SEARCH
CH MEMORY
```

(CH SETTING mode)

START

2.1 Press ***VOL (+)***. The tuner will search through all available channels in your area and add them into the TV's memory.

STOP

2.2 Press ***VOL (–)***. CH SEARCH will stop at the current channel and will not add any higher channels.

2.3 Press ***MENU*** to exit.




```
CH SEARCH

 AIR  12

        START : +
        STOP  : –
```

(CH SEARCH mode)

Note:

- If you press ***VOL (+)*** again while in the CH SEARCH mode, auto-program will start again, and the previously memorized channels will be lost.

■ **Adding weak or additional channels or erasing unwanted channels from TV memory.**

1.1 Press ***MENU*** to access MAIN MENU screen, then press ***CH UP*** (▲) or ***DOWN*** (▼) to move the "⇕" mark to "SET UP".

1.2 Press ***VOL (+)*** or ***(–)*** to access SET UP mode, then press ***CH UP*** (▲) or ***DOWN*** (▼) to move the "⇕" mark to "CH SETTING".

1.3 Press ***VOL (+)*** or ***(–)*** to access CH SETTING mode, then press ***CH UP*** (▲) or ***DOWN*** (▼) to move the "⇕" mark to "CH MEMORY".




```
EZ SETUP
AIR/CABLE
CH SEARCH
●CH MEMORY
```

(CH SETTING mode)

2.1 Press ***VOL (+)*** or ***(–)*** to access CH MEMORY.

2.2 Use ***CH UP*** (▲) or ***DOWN*** (▼) or ***REMOTE KEYPAD*** to select each desired channel to add or erase.

2.3 Press ***VOL (+)*** to add a channel to the TV's memory or press ***VOL (–)*** to erase a channel from the TV's memory.



Set Up (Continued)

2.4 Press ***MENU*** to exit.





(CH MEMORY unmemorized channel)

(CH MEMORY memorized channel)

■ **BLUE SCREEN**

Automatically turns the screen blue if a broadcast signal is not received.

---

1 Press ***MENU*** to access MAIN MENU screen.

2 Press ***CH UP*** (▲) or ***DOWN*** (▼) to move the "⇕" mark to "SET UP".





(MAIN MENU screen)

---

3 Press ***VOL (+)*** or ***(–)*** to access SET UP mode.





(SET UP mode)

---

4 Press ***VOL (+)*** or ***(–)*** to access BLUE SCREEN select mode.





(BLUE SCREEN select mode)

---

5 Press ***VOL (+)*** or ***(–)*** to select "ON".





---

6 Press ***MENU*** to exit.

Note:

- Poor reception due to weak signals, or too much noise might activate the BLUE SCREEN function despite the presence of a broadcast signal. To continue watching TV under these conditions, switch the BLUE SCREEN "OFF".
- While VCR input mode is selected, the BLUE SCREEN will not be shown on your TV even if the BLUE SCREEN is turned on.

Set Up (Continued)

■ **PERSONAL PREFERENCE**

By setting the PERSONAL PREFERENCE channels in advance, you can select your favorite channels easily.



1 Press ***MENU*** to access MAIN MENU screen.

2 Press ***CH UP*** **(▲)** or ***DOWN*** **(▼)** to move the "◆" mark to "SET UP".




```
TIMER
VIDEO ADJUST
AUDIO SELECT
CLOSED CAPTION
PARENT CONTROL
ENERGY SAVE
◆SET UP
```

(MAIN MENU screen)

3 Press ***VOL (+)*** or ***(–)*** to access SET UP mode, then press ***CH UP*** **(▲)** or ***DOWN*** **(▼)** to move the "◆" mark to "PERSONAL PREFERENCE".




```
BLUE SCREEN
◆PERSONAL PREF.
UNIVERSAL PLUS
LANGUAGE
CH SETTING
```

(SETUP mode)

4 Press ***VOL (+)*** or ***(–)*** to select PERSONAL PREFERENCE select mode in which you can program 4 favorite channels, in 4 different categories. (total of 16 channels)




```
PERSONAL PREF.
 <A>  B   C   D
◆--- --- --- ---
 --- --- --- ---
 --- --- --- ---
 --- --- --- ---
```

(PERSONAL PREFERENCE select mode)

5 Press ***CH UP*** **(▲)** or ***DOWN*** **(▼)** to move the "◆" mark to the desired position.

```
PERSONAL PREF.
 <A>  B   C   D
 --- --- --- ---
◆--- --- --- ---
 --- --- --- ---
 --- --- --- ---
```

6 Press ***REMOTE KEYPAD*** on the Remote to input the CHANNEL Number into the memory.

Example:

125 — Press "100" followed by "2" and then "5".




```
PERSONAL PREF.
 <A>  B   C   D
◆125 --- --- ---
 --- --- --- ---
 --- --- --- ---
 --- --- --- ---
```

7 Repeat steps 4 to 6 to input the next CHANNEL Number.

8 Press ***MENU*** to exit.

To select the PERSONAL PREFERENCE channel.

If the channels are memorized as shown to the right, press the Remote's "A" button to select the Channels below.

125 → 25 → 40 → 4

```
PERSONAL PREF.
 <A>  B   C   D
◆125  85  38 ---
  25 123  30 ---
  40  55 --- ---
   4 --- --- ---
```

Set Up (Continued)

■ **UNIVERSAL PLUS FUNCTION**

VCR or DVD input mode will be selected automatically by pressing VCR or DVD PLAY button on UNIVERSAL REMOTE CONTROL.



1 Press ***MENU*** to access MAIN MENU screen.

2 Press ***CH UP*** **(▲)** or ***DOWN*** **(▼)** to move the "⇕" mark to "SET UP".




```
  TIMER
  VIDEO ADJUST
  AUDIO SELECT
  CLOSED CAPTION
  PARENT CONTROL
  ENERGY SAVE
⇕SET UP
```

(MAIN MENU screen)

3 Press ***VOL (+)*** or ***(–)*** to access SET UP mode.




```
⇕BLUE SCREEN
 PERSONAL PREF.
 UNIVERSAL PLUS
 LANGUAGE
 CH SETTING
```

(SET UP mode)

4 Press ***CH UP*** **(▲)** or ***DOWN*** **(▼)** to move the "⇕" mark to "UNIVERSAL PLUS".

```
 BLUE SCREEN
 PERSONAL PREF.
⇕UNIVERSAL PLUS
 LANGUAGE
 CH SETTING
```

5 Press ***VOL (+)*** or ***(–)*** to access UNIVERSAL PLUS to select VCR or DVD mode.




```
UNIVERSAL PLUS

⇕VCR:  :OFF
 DVD:  :OFF
```

(UNIVERSAL PLUS select mode)

6 Press ***CH UP*** **(▲)** or ***DOWN*** **(▼)** to select the VCR or DVD, and press ***VOL (+)*** or ***(–)*** to select "CH3, CH4", "INPUT 1", "INPUT 2" or "OFF".

CH3 ↔ CH4 ↔ INPUT1 ↔ INPUT2 ↔ OFF

Set model to the input in which your VCR or DVD is connected to. If done through RF, select either channel 3 or 4 to match the setting of the VCR or DVD.




```
UNIVERSAL PLUS

⇕VCR:  :CH3
 DVD:  :OFF
```

7 Press ***MENU*** to exit.

PIP (Picture In Picture)

■ **With the VIDEO inputs, you can watch two pictures at the same time: one from the antenna or cable TV input and the other from the VIDEO input.**



■ **To view the Inset Picture.**

Press ***PIP***.

(Press the button to turn the Inset Picture on and off.)



■ **Channel Display when PIP is ON (4 seconds).**
Example:

Main Picture — 22

Inset Picture — VIDEO Input



■ **To select the Input for the Inset Picture.**

Press ***SELECT***.
(Each time you press the button, the picture will change as shown below.)



■ **To Swap the Main and Inset Pictures.**

Press ***SWAP***.
(Press the button to SWAP the pictures again.)

Example:



Main Picture → 22CH
Inset Picture → INPUT 1

Main Picture → INPUT 1
Inset Picture → 22CH

PIP (Picture In Picture) (Continued)

■ **To move the Inset Picture.**

Press ***MOVE***.
(Press the button again to move the Inset Picture to another position.)



■ **Freeze-Frame Inset Pictures**

- When the Inset Picture is on the screen, press ***FREEZE*** to freeze the Inset Picture.
  Only when the Main Picture is on the screen, press ***FREEZE*** to inset a freeze-frame of the Main Picture.
- Press ***FREEZE*** again to remove the Inset Picture.

Note:

- When the Main Picture's signal is black and white or the signal is lost, the Inset Picture may change to black and white. In this case, the Inset Picture may appear with a bit of vertical jagged lines depending on the type of receiving signal.

■ **How PIP behaves when V-CHIP BLOCK has been activated.**

PIP is ON and Main Picture is blocked.

When the Main Picture is blocked, Main Picture will change to blue screen and message "V-CHIP Has Been Activated" will be displayed.

Main Picture Channel No. displays but Insert Picture will be OFF.

This Message will remain on screen until V-CHIP BLOCK is temporarily canceled or you change the Main Picture to a TV program that is not blocked.



PIP is ON and Insert Picture is blocked.

When the Insert Picture is blocked, Insert Picture will change to a blue screen.

Main Picture is viewable but a message "V-CHIP Has Been Activated" will be displayed in the Main Picture.

This Message will remain on screen until V-CHIP BLOCK is temporarily canceled or you change the Insert Picture to a TV program that is not blocked.



Note:

- Please refer to page 23 on how to temporarily canceled V-CHIP BLOCK.

Using the Video and Audio Input Jacks

■ **Connecting video equipment for playback of video material.**

• When the television is connected to video equipment as shown below, the material being played back on the video equipment can be seen on the television screen.

Connecting video device equipped with video output terminals.

CONNECTIONS

VIDEO EQUIPMENT



CAMCORDER



TV GAME



VCR



DVD

(Front connection terminals of TV)



(Rear connection terminals of TV)



Using the Video and Audio Input Jacks (Continued)

Notes:
- The S-VIDEO INPUT terminals (IN-1) isused to obtain a higher quality image by importing signal separated into color and brightness signals.
- The S-VIDEO INPUT terminal is for image signal. Audio signal is to be connected to the IN 1 AUDIO terminals (left and right).



■ **To watch video material playback.**
- Press the Remote's ***INPUT*** to select VIDEO INPUT mode to which the video equipment you wish to play**.**
- The external VIDEO INPUT mode will change as follows each time the ***INPUT*** button is pressed.

AIR or CABLE → INPUT 1 (IN-1) Rear → INPUT 2 (IN-2) Front

- INPUT mode can be selected by pressing either the ***CH UP*** **(▲)** on the TV remote control when the TV is set to the highest channel stored in memory, or by pressing the ***CH DOWN*** **(▼)** when it is set to the lowest channel.

Note:
- When connecting video or audio equipment to the television, be sure that the power is turned off in order to prevent damage to either the television or the equipment being connected.
- S-Video terminal has priority over a VIDEO terminal (IN-1). When you want to watch pictures from video equipment connected to a VIDEO terminal, unplug equipment connected to the corresponding S-VIDEO terminal.
- It is the intent of SHARP that this product be used in full compliance with the copyright law of the United States and that prior permission be obtained from copyright owners whenever necessary.
- For detailed information on the connection and use of auxiliary equipment, refer to the instruction manuals of the equipment being used.
- The connection cords can be obtained from your local video store.

Using the Audio Output Jacks

■ **These jacks are used for connecting a standard studio amplifier. Control of STEREO/MONO/SAP, VOLUME, and MUTE are retained at the TV. These jacks relay the audio signal of all programs being displayed on the TV screen.**

(AUDIO OUTPUT JACKS are located on the rear of the cabinet.)

CONNECTIONS

(RearconnectionterminalsofTV)



(1) Before connecting the cord, turn on the TV and adjust the VOLUME control on the TV for a moderate listening level.
(2) Turn off the TV and connect the audio cord to the AUDIO LINE OUTPUT JACKS on the TV.
(3) Turn the TV set and stereo amplifier on.
(4) If you desire, you can turn off the sound to the TV's internal speakers by SPEAKER mode. See page 14, 15.
(5) Adjust the VOLUME control on the stereo amplifier for a moderate listening level.
(6) Control of the audio can be done using the audio controls (STEREO/MONO/SAP, VOLUME, and MUTE), from either the remote control, or directly from the TV set.

Note:

- For detailed information on the connection and use of auxiliary equipment, refer to the operation manuals of the equipment being used.
- When connecting monaural equipment to the AUDIO INPUT or OUTPUT of this set, use an audio connection cord and plug adaptor as shown below.
- For optimal sound quality, it is recommended to keep the TV's audio output level high.



Operation of Remote Control

■ Universal Remote Control

With the purchase of your television set you also have received the latest innovation in remote control technology. With its easy-to-use push button keyboard, your Remote can control your television set and most infrared remote controlled VCRs, cable TV converters and DVDs as well.

Note:

- Depending on the model year produced, brand and type of VCR, cable TV converter and DVD, some models may not be compatible with the remote control.
- Some brands may not enable channel selection until the ENTER button is pressed.

Example:
When you select channel 24,
(1) Press REMOTE KEYPAD "2".
(2) Press REMOTE KEYPAD "4".
(3) Press ENTER.
For detailed information on the use of the Cable TV converter Box refer to their operating manuals.

■ Using Your Remote With Your TV

After installing the batteries, set the ***CATV/ DVD-TV/VCR*** on the remote to the TV position. (If you can change the channel of the TV by pressing ***CH UP*** (▲) or ***DOWN*** (▼) on the Remote Control, it is the TV position.)

■ "Identifying" Remote VCRs, cable TV conveters and DVDs

Your Remote Control has been set at the factory to operate your TV and many remote control VCRs, cable TV converters and DVDs. However, in some cases an easy one-time set-up step may be necessary before the Remote will operate accessory VCRs, cable TV converters and DVDs.

- In this set-up step, the Remote locates and memorizes the remote control transmitter code for the VCR, cable TV converters and DVDs.
- Once "identified", the Remote sends the proper remote signals to operate your accessory.
- This identify step will not have to be repeated until power to the Remote is interrupted due to a battery failure.

■ USING YOUR REMOTE CONTROL WITH A VCR

Once you are make certain the Remote Control has "identified" your remote controlled VCR or DVD, the Remote Control is ready to operate your unit. The various VCR or DVD function buttons on the Remote Control will not operate your VCR or DVD if those features are not already found on your unit.

- All VCR buttons will operate whether the Remote Control is in TV or VCR modes.
- For detailed information on the use of the VCR or DVD, refer to the operation manual of the VCR or DVD.



DVD/VCR POWER
Press to turn the VCR or DVD on and off.

PLAY ►
Press to playback a tape or disc.

REWIND ◄◄
Press to rewind a tape or reverse a disc. For some VCRs or DVDs you may need to press STOP first, then REWIND.

PAUSE II
Press to temporarily stop the tape or disc during playback or recording (VCR only).
Press again to release Pause.
For some VCRs or DVDs you may need to press STOP first,

STOP ■
Press to stop the tape or disc.

REMOTE KEYPAD
Use to enter two-digit code numbers when identifying your VCR.

ENTER

FF ►►
Press to rapidly advance the tape or disc. For some VCRs or DVDs, you may need to press STOP first, then FF.

VCR CHANNEL UP (▲)/ DOWN (▼)
Press to scan up or down through channels on the VCR.

DVD SKIP
Press to jump forward to the beginning of the next chapter/track, or backward to the beginning of the current chapter/track, and automatically start to play that chapter/track.

RECORD ●
Press to begin recording. (VCR only)

Operation of Remote Control (Continued)



■ **HOW TO IDENTIFY A VCR**

The remote control may already be set to operate your VCR. Try this initial check before going on to the following "identify" section.

(1) Slide ***CATV/DVD-TV/VCR*** switch to VCR.
(2) Point remote towards VCR and press ***DVD/ VCR POWER***.
(3) Does the remote turn the VCR ON and OFF?
- If yes, the remote is ready to operate the VCR and no further steps are needed.
- If no, continue to the "identify" section.

■ **To Identify Your VCR – Direct Entry Method.**

Use the following steps and list to quickly find the remote control code for your accessory VCR.
- First look up your VCR's remote control code number before going through the direct code entry steps control.
- If this procedure does not identify your accessory VCR, use the Search method of identification (described in the next section).

(1) Slide ***CATV/DVD-TV/VCR*** switch to VCR.
(2) Press and hold down ***DISPLAY*** and ***CH DOWN (▼)*** on your remote control. Then release both buttons.
(3) Within ten seconds after releasing ***DISPLAY*** and ***CH DOWN (▼)*** , enter your VCR's two-digit remote control code number using the ***REMOTE KEYPAD*** (refer to list).
- The remote control is now ready to send commands to your VCR.

Some brands have more than one remote code listed, due to changes in the remote codes from early to later model years, or due to format differences (VHS/BETA). In such cases, you may have to try more than one code to find the code your VCR accepts.

Note:

Depending on the model, year produced, brand, and type of VCR, some models may not be compatible with the remote control.

■ **To Identify Your VCR – Search Method.**

(1) Slide ***CATV/DVD-TV/VCR*** switch on the remote to VCR.
(2) Press POWER on the VCR to ON.
(3) Stand at least six feet away from the front of the VCR.
Point the remote towards the VCR.
Hold down ***DISPLAY*** and ***CH UP (▲)*** at the same time. KEEP HOLDING THE BUTTONS DOWN.
(4) Watch the Channel Number indicator on the VCR, Channel numbers will scan up when the VCR has been identified.
Release ***DISPLAY*** and ***CH UP (▲)*** as soon as the channel numbers start to scan up.
The VCR's remote control code number has been identified, and the remote is ready to operate the VCR.

Operation of Remote Control (Continued)



TIPS ON IDENTIFYING YOUR VCR:

If your VCR model does not have the CHANNEL UP function on its remote control, it cannot be identified using the SEARCH method for identifying. For such models, please try the DIRECT ENTRY method of identifying.

Be Patient: a minute or two can seem a lot longer when you're waiting for something to happen, but the code should be identified within 2 minutes. Remember, it is only a one-time set-up.

Be careful not to let the VCR scan more than five channels when the indicator starts to move up. If you continue holding down the ***DISPLAY*** and ***CH UP (▲)*** after five channel scans, the proper remote code can be passed up, and the two minutes identify cycle will have to be repeated.

If a channel change does not occur on the VCR within two minutes, read the identifying instructions again and repeat the steps. Should a channel change still not occur the remote will not operate with the desired VCR.

VCR BRAND	REMOTE CONTROL CODE NUMBER
Akai	25, 26, 37
Audio Dynamics	15, 22, 30
Broksonic	32
Canon	04
Capehart	34
Craig	10, 31
Curtis Mathis	04
Daewoo	34
DBX	15, 22, 30
Dynatech	29
Emerson	21, 32, 35
Fisher	09, 10, 11
Funai	28, 29
GE	04
Goldstar	24
Hitachi	06
Instant Replay	04
JC Penney	04, 06, 24, 30
JVC	15, 41, 42
Kenwood	14, 15
Lloyds	29
Magnavox	04, 05, 08
Magnin	31
Marantz	30
Memorex	04, 10, 24, 29
Minolta	06
Mitsubishi	17, 18, 39, 40
Montgomery Ward	02, 43
Multitech	29
NEC	15, 22, 30
Panasonic	04, 44
Pentax	05, 06
Philco	04, 05
Philips	04, 05, 08
Quasar	04
RCA	06, 07, 33
Realistic	01, 02, 10, 24
Samsung	23, 31
Sanyo	14, 10
Scott	20
Sears	06, 11, 24
Sharp	01, 02, 03
Shintom	36
Sony	12, 13, 38
Sound Design	29
Sylvania	04, 05, 08
Symphonic	29
Tatung	15
Teac	15, 29
Teknika	27, 29
Thomas	29
TMK	21
Toshiba	19, 20
Video Concepts	30
Yamaha	15, 29, 30
Zenith	16

Operation of Remote Control (Continued)



■ **HOW TO IDENTIFY A DVD**

The remote control may already be set to operate your DVD. Try this initial check before going on to the following "identify" section.

(1) Slide ***CATV/DVD-TV/VCR*** switch to DVD.
(2) Point remote towards DVD and press ***DVD/ VCR POWER***.
(3) Does the remote turn the DVD ON and OFF?
- If yes, the remote is ready to operate the DVD and no further steps are needed.
- If no, continue to the "identify" section.

■ **To Identify Your DVD – Direct Entry Method.**

Use the following steps and list to quickly find the remote control code for your accessory DVD.
- First look up your DVD's remote control code number before going through the direct code entry steps control.

(1) Slide ***CATV/DVD-TV/VCR*** switch to DVD.
(2) Press and hold down ***INPUT*** and ***CH DOWN (▼)*** on your remote control. Then release both buttons.
(3) Within ten seconds after releasing ***INPUT*** and ***CH DOWN (▼)*** , enter your DVDs two-digit remote control code number using ***REMOTE KEYPAD*** (refer to list).
- The remote control is now ready to send commands to your DVD.

DVD BRAND	REMOTE CONTROL CODE NUMBER
Denon	02
JVC	09
Magnavox	04
Marantz	04
Mitsubishi	06
Panasonic	02
Philips	04
Pioneer	08
Proscan	03
RCA	03
Samsung	07
Sharp	01
Sony	05
Toshiba	04
Yamaha	02
Zenith	04

Note:

Depending on the model, year produced, brand, and type of DVD, some models may not be compatible with the remote control.

Operation of Remote Control (Continued)

■ **HOW TO IDENTIFY A CABLE CONVERTER**

■ **To Identify Your Cable Converter –Direct Entry Method.**

Use the following steps and list to quickly find the remote control code for your cable TV converter.

- First look up your converter's remote code number before going through the direct code entry steps below.
- If this procedure does not identify your converter, use the Search method for identification.

(1) Slide ***CATV /DVD-TV/VCR*** switch to CATV.
(2) Press and hold down ***DISPLAY*** and ***CH DOWN (▼)*** on your remote control. Then release both buttons.
(3) Within ten seconds after releasing ***DISPLAY*** and ***CH DOWN (▼)***, enter your converter's two-digit code number using ***REMOTE KEYPAD*** (refer to list).

- The remote control is now ready to send commands to your converter.
- Some brands have more than one remote code listed due to changes in the remote codes from early to later model years. In such cases, you may have to try more than one code to find the code your converter accepts.

Note:

Depending on the model, year produced, brand, and type of CATV converter, some models may not be compatible with the remote control.

■ **To Identify Your Cable Converter – Search Method.**

(1) Slide the ***CATV /DVD-TV/VCR*** switch to CATV.
(2) Press the POWER button on the cable converter to ON.
(3) Stand at least six feet away from the converter. Point the remote towards the converter. Hold down the ***DISPLAY*** and ***CH UP (▲)*** at the same time. KEEP HOLDING THE BUTTONS DOWN.
(4) Watch the Channel Number indicator on the converter. Channel numbers will scan up when the converter has been identified. Release the ***DISPLAY*** and ***CH UP (▲)*** as soon as the channel numbers start to scan up. The converter's remote control code number has been identified, and the remote is ready to operate the converter.

CATV CONVERTER BRAND	REMOTE CONTROL CODE NUMBER
Anvision	07, 08
Cable Star	07, 08
Eagle	08
General Instrument	04, 05, 15, 23, 24, 25, 30, 36
Jerrold	04, 05, 15, 23, 24, 25 30, 36
Magnavox	07, 08, 19, 25, 28, 29, 32, 33, 40, 41
Oak Sigma	18
Panasonic	27, 39
Philips	07, 08, 19, 26, 28, 29, 32, 33, 40, 41
Pioneer	18, 20
Randtek	07, 08
RCA	27, 43
Scientific Atlanta	03, 22, 42
Sony	44
Viewstar	07, 08, 19, 26, 28, 29 32, 33, 40, 41
Zenith	14

TIPS ON IDENTIFYING YOUR CABLE CONVERTER:

Be Patient: a minute or two can seem a lot longer when you're waiting for something to happen, but the code should be identified within 2 minutes. Remember, it is only a one-time set-up.

Be careful not to let the CATV converter scan more than five channels when the indicator starts to move up. If you continue holding down the ***DISPLAY*** and ***CH UP (▲)*** after five channel scans, the proper remote code can be passed up, and the two minute identify cycle will have to be repeated.

If a channel change does not occur on the cable converter within two minutes, read the identifying instructions again and repeat the steps. Should a channel change still not occur, the remote will not operate with the desired converter.

Note:

Some satellite receivers can be operated by the REMOTE CONTROL. If you have a Satellite Receiver, you can use the above method to search for available channels.

Before Calling for Service

Check these items and see if you can correct trouble with a slight adjustment of the controls.

QUICK SERVICE CHECK LIST / PROBLEM / POSSIBLE REMEDY	No Playback of VCR and Disk Player	No Picture or Sound from External Video/Audio Products	Remote Control Doesn't Work	Bars on Screen	Picture Distorted	Picture Rolls Vertically	No Color	Poor Reception on Some Channels	Weak Picture	Lines or Streaks in Picture	Ghosts in Picture	Picture Blurred	Sound OK, Picture Poor	Picture OK, Sound Poor	No Picture or Sound	Dark and Blank Picture	External Electrical Noise Interfering with TV's Operation	Color on Part of the Screen Appears Distored
Try a new channel, if OK, then possible station trouble.					X	X	X	X	X	X	X	X	X	X	X			
Is TV plugged in? Power at outlet?		X	X												X			
Is TV's POWER button on?		X													X			
Is antenna connected to terminal on the back of the set?							X	X	X		X		X		X			
If outside antenna is being used, check for broken wire.				X	X	X	X	X	X	X	X	X	X		X			
Check for local interference or external electrical noise.				X		X		X		X	X		X	X			X	
Turn off with POWER button and then turn it on after about a minute.		X													X			
Adjust COLOR control.							X											
Adjust PICTURE control.									X				X					
Check external Video/Audio products: look for loose/broken connection leads. (Refer to page 36, 37)	X	X											X	X	X			
Check batteries of Remote Control.			X															
Slide CATV/DVD-TV/VCR Select Switch to TV position.			X															
Are audio cables connected firmly? Check the volume level.															X			
Is SPEAKER ON? See page 14, 15.															X			
Change Closed Caption mode to "OFF" / Energy Save mode to "OFF".																X		
Unplug the TV and plug it in again after two minutes.			X			X	X	X	X				X	X	X	X	X	X

Note:

- When viewing in TEXT mode, if no TEXT broadcast is being received, the screen may become dark and blank. Should this occur, set the Closed Caption mode to "OFF".

(Dark and Blank Picture)

Calling for Service

For location of the nearest Sharp Authorized Service, or to obtain product literature accessories, supplies, or customer assistance, please call 1-800-BE-SHARP.

Antes de llamar al servicio de reparaciones

Verifique estos items para ver si usted mismo puede solucionar el problema.

LISTA DE COMPROBACIONES DE SERVICIO RAPIDO / PROBLEMA POSIBLE SOLUCIÓN	El vídeo o el reproductor de discos de vídeo no reproducen imágenes	El equipo de vídeo/audio externo no produce imágenes ni sonido	El mando a distancia no funciona	Barras en la pantella	Imagen distorsionada	La imagen se desplaza verticalmente	No hay color	Mala recepción de algunos canales	Imagen débil	Franjas en la imagen	Imagen fantasma	Imagen borrosa	Sonido adecuado, imagen mala	Imagen adecuada, sonido malo	No hay imagen ni sonido	Imagen oscura y en blanco	Interferencia de ruido eléctrico externo con el funcionamento del televisor	El color se ve distorsionado en parte de la pantalla
Pruebe con otro canal y si todo está bien, el problema puede ser de la emisora.					X	X	X	X	X	X	X	X	X	X	X			
Está conectado el televisor? Llega electricidad al tomacorrientes?		X	X												X			
Está conectado el interruptor del televisor?		X													X			
Está conectado la antena al terminal del panel posterior del televisor?							X	X	X		X		X		X			
Si utiliza una antena exterior, cerciórese de que el cable no esté dañado.				X	X	X	X	X	X	X	X	X	X		X			
Compruebe si hay interferencia local.				X		X		X		X	X		X	X			X	
Desconecte el interruptor POWER y vuelva a conectarlo después de transcurrir un minuto.		X													X			
Ajuste el control de COLOR.							X											
Ajuste el control de MATIZ.									X				X					
Verifique los productos externos de Video/Audio, revise si hay fugas de conexiones sueltas o rotas.	X	X											X	X	X			
Compruebe el estado de las pilas del mando a distancia.			X															
Deslice CATV/DVD-TV/VCR selector para situarlo sobre la posición TV.			X															
Están bien conectados los cables de sonido? Compruebe el nivel del volumen.															X			
Está conectado el altavoz?															X			
Desactive (OFF) el modo CLOSED CAPTION / Desactive (OFF) el modo Ahorro de Energía (Energy Save).																X		
Desenchufe el televisor y vuelva a enchufarlo despúes de dos minutos.			X			X	X	X	X				X	X	X	X	X	X

Nota:

- Cuando se ve en modo TEXTO sin recibir emisiones de TEXTO, la pantalla puede ponerse en blanco y negro. Si ocurriera ésto, ponga el modo CLOSED CAPTION en OFF.

(Imagen oscura y en blanco)

Specifications

MODEL		32R-S400	36R-S400
Receiving System		NTSC	
Reception Channels			
AIR	VHF	2-13 ch	
	UHF	14-69 ch	
CATV		1-125 ch	
Channel Tuning		181-channel Reception PLL tuning system	
Antenna Input Impedance		VHF/UHF 75 ohm Unbalance	
Screen Size		32″ Diagonally Measured	36″ Diagonally Measured
Terminals		Audio/Video input x 2 (Front x 1, Rear x 1) S-Video input x 1 (rear)	
Sound Output		3.0 W (RMS) x 2	
Power Source		AC 120 V, 60 Hz	
Power Consumption		140 W	165 W
Dimensions [(W) x (H) x (D)]mm		$30^{21}/_{64}$″ x $26^{7}/_{8}$″ x $21^{57}/_{64}$″ [784.0 x 682.0 x 555.0]	$34^{47}/_{64}$″ x $29^{55}/_{64}$″ x $24^{25}/_{32}$″ [882.0 x 758.0 x 629.0]
Weight (approx.)		114.6 lbs. (52.0 kg)	154.0 lbs. (70.0 kg)

• Design and specifications are subject to change without notice.

Limited Warranty

CONSUMER LIMITED WARRANTY

SHARP ELECTRONICS CORPORATION warrants to the first consumer purchaser that this Sharp brand product (the "Product"), when shipped in its original container, will be free from defective workmanship and materials, and agrees that it will, at its option, either repair the defect or replace the defective Product or part thereof with a new or remanufactured equivalent at no charge to the purchaser for parts or labor for the period(s) set forth below.

This warranty does not apply to any appearance items of the Product nor to the additional excluded item(s) set forth below nor to any Product the exterior of which has been damaged or defaced, which has been subjected to improper voltage or other misuse, abnormal service or handling, or which has been altered or modified in design or construction.

In order to enforce the rights under this limited warranty, the purchaser should follow the steps set forth below and provide proof of purchase to the servicer.

The limited warranty described herein is in addition to whatever implied warranties may be granted to purchasers by law. ALL IMPLIED WARRANTIES INCLUDING THE WARRANTIES OF MERCHANTABILITY AND FITNESS FOR USE ARE LIMITED TO THE PERIOD(S) FROM THE DATE OF PURCHASE SET FORTH BELOW. Some states do not allow limitations on how long an implied warranty lasts, so the above limitation may not apply to you.

Neither the sales personnel of the seller nor any other person is authorized to make any warranties other than those described herein, or to extend the duration of any warranties beyond the time period described herein on behalf of Sharp.

The warranties described herein shall be the sole and exclusive warranties granted by Sharp and shall be the sole and exclusive remedy available to the purchaser. Correction of defects, in the manner and for the period of time described herein, shall constitute complete fulfillment of all liabilities and responsibilities of Sharp to the purchaser with respect to the Product, and shall constitute full satisfaction of all claims, whether based on contract, negligence, strict liability or otherwise. In no event shall Sharp be liable or in any way responsible, for any damages or defects in the Product which were caused by repairs or attempted repairs performed by anyone other than an authorized servicer. Nor shall Sharp be liable or in any way responsible for any incidental or consequential economic or property damage. Some states do not allow the exclusion of incidental or consequential damages, so that above exclusion may not apply to you.

THIS WARRANTY GIVES YOU SPECIFIC LEGAL RIGHTS. YOU MAY ALSO HAVE OTHER RIGHTS WHICH VARY FROM STATE TO STATE.

Model Specific Section

Your Product Model Number & Description:	32R-S400/36R-S400, 32/36 inch Color Television (Be sure to have this information available when you need service for your Product.)
Warranty Period for this Product:	One (1) year parts and labor. The warranty period continues for an additional one (1) year, for a total of two (2) years, with respect to the picture tube(s) in the Product for parts only. Labor and service are not provided free of charge for this additional period.
Additional Item(s) Excluded from Warranty Coverage (if any):	Non-rechargeable batteries.
Where to Obtain Service:	From a Sharp Authorized Servicer located in the United States. To find the location of the nearest Sharp Authorized Servicer, call Sharp toll free at 1-800-BE-SHARP.
What to Do to Obtain Service:	Contact your Sharp Authorized Servicer to obtain in-home service for this Product. The Servicer will come to your home and if it is necessary to remove the Product, the Servicer will reinstall it. Be sure to have **Proof of Purchase** available.

SHARP

SHARP ELECTRONICS CORPORATION

Sharp Plaza, Mahwah, New Jersey 07430-2135

Printed in Mexico
TINS-7366GJZZ
1P03-MMP